



**READ INSTRUCTIONS BEFORE
SETTING UP THE TENT**

SUN BEACH SHADE


1. Unpack the shelter and the 3 poles from the carry bag




2. Assemble each section of the poles together. The Grey pole (x1) will be longer than the Black poles (x2)




3. Carefully insert the GREY pole through the pole sleeve on the side of the tent




4. Carefully insert the two BLACK poles through the pole sleeves in from the back



5. Carefully Insert each end of the 3 poles into the corresponding grommets



6. Use Sand Pockets for added stability on soft/beach surfaces and the ground stakes on firm surfaces



7. Now you're all Set up and READY



WARNING: KEEP BODY PARTS CLEAR OF POLE JOINTS DURING OPERATION.

WARNING: KEEP ALL FLAME AND HEAT SOURCES AWAY FROM THIS TENT FABRIC. This tent meets the flammability requirements of CPAI-84. This tent is made of flame-resistant fabric. It is not fireproof. The fabric will burn if left in continuous contact with a flame source. The application of any foreign substance to the tent fabric may render the flame-resistant properties ineffective.

WARNING
KEEP ALL FLAME AND
HEAT SOURCES AWAY
FROM THIS TENT
FABRIC

This tent meets the flammability requirements of CPAI-84. The fabric may burn if left in continuous contact with any flame source.

The application of any foreign substance to the tent fabric may render the flame-resistant properties ineffective.

EXTREME CAUTION

Never use any fuel burning oxygen consuming devices or any devices that produce any fumes, including stoves, lanterns, candles, hibachis or heaters in or around your tent. This could result in carbon monoxide poisoning, injury and/or death.

MADE IN CHINA



WARNING

THIS RECREATIONAL ITEM IS NOT INTENDED FOR USE AS A PERMANENT STRUCTURE

This Tent/Shelter has been developed and is intended to provide protection from sun and light rain. DO NOT use any gas or flame sources under or near this product. This product is NOT WATERPROOF.

Excess water build-up can cause the frame system to become unstable, and collapse, causing injury. Any personal accessories or modifications to product should be removed before the onset of inclement weather such as heavy rain, wind, lightning, hail, snow, etc. This product should be completely dismantled to avoid permanent damage to product components and avoid any possibility of personal injury. This product is not a toy. This product is not designed for use by children without adult supervision. Under no circumstances should this product be used as a permanent or temporary storage facility for children's toys, garden tools, personal belongings or similar valuables. Consumer-made modifications for extended use, i.e. permanently securing to decks and patios and/or Consumer's failure to follow stated guidelines, will invalidate any Eusebio Sporting Goods warranty, expressed or implied.

CARE & STORAGE

Your product is NOT machine washable. Your product is NOT machine dryable.

One of the easiest ways to damage your product is storing it while wet. If you must close camp in the rain, follow these guidelines carefully:

- As Soon As Possible: Open your product and ensure that every area of fabric is clean and completely dry before rolling up for storage.
- If necessary, hang product outside or loosely drape over a ladder in your garage or spare room for a few days, turning it inside and out to prevent trapping pockets of water or debris.
- Use a soft brush to wipe away surface dirt.

To clean your product: Hand wash using a mild dishwashing soap and soft bristle brush, then allow the fabric to completely air dry.

Don't neglect the frame: Wipe down all parts - steel, plastic, and fiberglass - before putting away for next season's use. Salts from ocean air can and do affect damage if not dealt with as quickly as possible.

Storing a wet fabric for as little as 24 hours in warm weather is likely to cause fabric to mildew. Once mildew sets in, the stains are permanent. Stains cannot be removed without potential harm to the fabric's coatings; chemicals or cleaning agents used to remove dirt and stains may irreversibly harm the fabric.

Salts, mildew and other causes and subsequent effects are NOT covered under the limited warranty.